

## **EQUIPMENT KIT CHECKLIST**

### **ARRI 1K FLOOD KIT**

#### **OPERATION AND SAFETY:**



##### **ELECTROCUTION HAZARD**

All instruments must be grounded (earthed). Never use ground-bypass adapters!



##### **FLAMMABLE HEAT**

Instruments operate at high temperatures. Do not operate upside-down!

Do not operate in the presence of flammable materials!

Maintain 3ft distance between instruments and surroundings!



##### **BURN-RELATED INJURY**

Instruments may remain extremely hot during and after operation.

May cause burns! Use protective gear! Before packing or handling, allow at least 10 minutes time for instruments to cool!

#### **PACKING AND STORAGE:**

##### **IMPROPERLY OR MESSILY PACKED KITS WILL RESULT IN A FINE!**

The Arrilite 1000 is packed on its side, facing to the case's rear, as labeled on foam.

Barndoor is packed separately, adjacent left of the instrument, as labeled on foam.

AC Mains Cable should be neatly wrapped in alternating loops, and bound with their Velcro strap, fuzzy-side out. Lay the AC Cable on top of barndoor, as labeled on foam.

Do not pinch AC Mains Cable in case lid!

Do not throw away expired/broken lamps! Pack them in replacement lamps' boxes. The Equipment Checkout Lab will dispose of them properly! Borrowers will be billed for missing lamps!

NOTE: Lighting Stands are not included with this kit. Do not attempt to pack stands in this kit!

##### **PACKING EXAMPLE:**



In the event of accident or mishap with this equipment, contact the F&DM Checkout Lab Specialist IMMEDIATELY: Phone (831) 459-4062 – Email [fdmcheckout@ucsc.edu](mailto:fdmcheckout@ucsc.edu)

**IN THE EVENT OF MEDICAL EMERGENCY, DIAL 911.**