

Frame Assembly:

- Small 4 Corner Pieces
- Medium 4 Corner Pieces
 2 Extensions

96" X 96"

- Large 4 Corner Pieces 4 Extensions
- X-Large 4 Corner Pieces 8 Extensions

Fabric Attachment:

- 1. Attach all four Velcro corner tabs securely
- 2. Connect velcro around perimeter

Re-packing Frame:

- 1. Build 2 layers (as shown below)
- 2. Place one on top of the other, velcro to velcro

