

EQUIPMENT KIT CHECKLIST

ARRI-FRESNEL KIT

OPERATION AND SAFETY:



ELECTROCUTION HAZARD

All instruments must be grounded (earthed). Never use ground-bypass adapters!



FLAMMABLE HEAT

Instruments operate at high temperatures. Do not operate upside-down!

Do not operate in the presence of flammable materials!

Maintain 3ft distance between instruments and surroundings!



BURN-RELATED INJURY

Instruments may remain extremely hot during and after operation.

May cause burns! Use protective gear! Before packing or handling, allow at least 10 minutes time for instruments to cool!

PACKING AND STORAGE:

IMPROPERLY OR MESSILY PACKED KITS WILL RESULT IN A FINE!

All attachments and accessories should be packed separately: barndoors stacked back-to-back, snoots smaller-into-larger, and placed into their respective slots. Pack instruments face-down.

AC Mains Cable should be neatly wrapped in alternating loops, and bound with their Velcro strap, fuzzy-side out. Do not pinch AC Mains Cable in case lid!

Light Stands should be collapsed, and stored in their compartment, at the front of the case.

PACKING EXAMPLE:

Gels and Gel Clips are stored in their respective storage containers, Scrims are packed in their scrim-bag, and all are stored behind the case foam.

Spare lamps are packed into holes for their box containers.

Gloves and Variable Dimmer are tucked into the light stands' compartment.

Do not throw away expired/broken lamps! Pack them in replacement lamps' boxes. The Equipment Checkout Lab will dispose of them properly! Borrowers will be billed for missing lamps!



In the event of accident or mishap with this equipment, contact the F&DM Checkout Lab Specialist **IMMEDIATELY**: Phone (831) 459-4062 – Email fdmcheckout@ucsc.edu

IN THE EVENT OF MEDICAL EMERGENCY, DIAL 911.