

## **EQUIPMENT KIT CHECKLIST LOWEL PORTRAIT KIT**

### **OPERATION AND SAFETY:**



#### **ELECTROCUTION HAZARD**

All instruments must be grounded (earthed). Never use ground-bypass adapters!



#### **FLAMMABLE HEAT**

Instruments operate at high temperatures. Do not point down while operating!

Do not operate in the presence of flammable materials!

Maintain 3ft distance between instruments and surroundings!



#### **BURN-RELATED INJURY**

Instruments may remain extremely hot during and after operation.

May cause burns! Use protective gear! Before packing or handling, allow at least

10 minutes time for instruments to cool!

### **PACKING AND STORAGE:**

#### **IMPROPERLY OR MESSILY PACKED KITS WILL RESULT IN A FINE!**

Pack Spare Lamps, Omni Scrim and Operating Instructions in the case-top mesh compartment.

All Instruments, Power Cables, Gloves, Boom Arm and Counter-Weight, and Umbrella are packed underneath the long top velcro partition.

Instruments are packed in their own respective foam compartments as follows, from left to right: Pro, Omni, Tota. They should be packed with Barndoors and/or Protective Screens attached (except the Gel Frame, which is packed separately in the Tota compartment).

Power Cables should be neatly wrapped, and bound with their Velcro strap, fuzzy-side out. Place into corresponding instrument compartment.

Lay the Umbrella and Boom Arm on top of the individual instrument compartments.

Pack the Gloves and Counter-Weight separately, with the Gel Frame in the Tota compartment.

Affix the long top velcro partition back into place, and store the collapsed Light Stands on top.



#### **PACKING EXAMPLES**



Do not throw away expired/broken lamps! Pack them in replacement lamps' boxes. The Equipment Checkout Lab will dispose of them properly! Borrowers will be billed for missing lamps!

In the event of accident or mishap with this equipment, contact the F&DM Checkout Lab Specialist IMMEDIATELY: Phone (831) 459-4062 – Email [fdmcheckout@ucsc.edu](mailto:fdmcheckout@ucsc.edu)

**IN THE EVENT OF MEDICAL EMERGENCY, DIAL 911.**