

EQUIPMENT KIT CHECKLIST

LOWEL TRIPLE KIT

OPERATION AND SAFETY:



ELECTROCUTION HAZARD

All instruments must be grounded (earthed). Never use ground-bypass adapters!



FLAMMABLE HEAT

Instruments operate at high temperatures. Do not point down while operating!

Do not operate in the presence of flammable materials!

Maintain 3ft distance between instruments and surroundings!



BURN-RELATED INJURY

Instruments may remain extremely hot during and after operation.

May cause burns! Use protective gear! Before packing or handling, allow at least 10 minutes time for instruments to cool!

PACKING AND STORAGE:

IMPROPERLY OR MESSILY PACKED KITS WILL RESULT IN A FINE!

Instruments should be packed with Barndoors and/or Scrims attached.

The Omnis are packed face-down in the two small compartments, the Tota and Gloves are packed in the side compartment, and the Power Cables are packed in the top long compartment.

Power Cables should be neatly wrapped in a figure-eight pattern, and bound with their Velcro strap, fuzzy-side out.

PACKING EXAMPLE:

Collapsed Light Stands are placed on top of the packed instruments and cables.

Take care not to snag or bend the Omnis' barndoors!

Spare Lamps, Operating Instructions, and collapsed Gel Frame and Tota-brella are packed in the mesh compartment of the soft-case lid.

Do not throw away expired/broken lamps! Pack them in replacement lamps' boxes.

The Equipment Checkout Lab will dispose of "dead" lamps properly!

Borrowers will be billed for missing lamps!



In the event of accident or mishap with this equipment, contact the F&DM Checkout Lab Specialist **IMMEDIATELY**: Phone (831) 459-4062 – Email fdmcheckout@ucsc.edu

IN THE EVENT OF MEDICAL EMERGENCY, DIAL 911.