EQUIPMENT KIT CHECKLIST PANASONIC AG-HMC150PJ KIT

OPERATION AND SAFETY:



ELECTROSTATIC SENSITIVE DEVICE

The SDHC card is sensitive to Electrostatic Discharge (ESD). Take extreme care when handling to protect the gold contacts from static shock. <u>ESD will destroy the SDHC Card</u>! <u>Store loose spare cards in their plastic cases!</u>



LINE VOLTAGE THRESHOLD

This camcorder can provide optional 48V Phantom-power for microphones. <u>Do not engage</u> Phantom-power in conjunction with battery-powered microphones! <u>To do so will overload and damage</u> the XLR jack!

PACKING AND STORAGE:

IMPROPERLY OR MESSILY PACKED KITS WILL RESULT IN A FINE!

<u>IMPORTANT</u>: The SDHC Card <u>must</u> be packed in either the camcorder's <u>SD Card Slot</u>, or its <u>plastic storage case</u>. Make sure the SD Card Slot Lid is <u>closed</u> for packing!

Camcorder is packed <u>on its base</u>, lens facing to the right. Pack with LCD closed, screen facing in, and lens cap on to protect lens. Remove Li-Ion Battery for packing.

Wrap all Power Cables in a figure-eight pattern, and bind with their velcro strap, fuzzy-side out. Store all power cables, Li-Ion and AA batteries, and AC Adapter in their clear-vinyl zipper wallet.

Pack the second 16GB SDHC Card and USB SD Card Reader in the clear-vinyl zipper wallet with the power components. <u>Take care not to crush or bend the SDHC Card or USB SD Card Reader</u>!

Wrap XLR Cable in broad, alternating loops, and bind with velcro-strap, fuzzy-side out. Place the XLR Cable in the main storage slot first, then clear-vinyl zipper wallet on top.



Lastly pack the shotgun mic on top, fitting the shockmount-end into its corresponding foam recess. The condenser capsule should be attached. The pistol grip is packed loose in the remaining space. <u>Do not leave the AA battery in the mic!</u> Pack it in the clear-vinyl zipper wallet!

Operating Manual is stored behind the case lid foam. Do not pinch cables in case lid!



In the event of accident or mishap with this equipment, contact the F&DM Checkout Lab Specialist <u>IMMEDIATELY:</u> Phone: (831) 459-4062 Email: fdmcheckout@ucsc.edu

IN THE EVENT OF MEDICAL EMERGENCY, <u>DIAL 911</u>.