

## **EQUIPMENT KIT CHECKLIST SONY XDCAM EX KIT**

### **OPERATION AND SAFETY:**



#### **ELECTROSTATIC SENSITIVE DEVICE**

The SDHC and SxS Cards, and MxR/SxS Adaptor are sensitive to Electrostatic Discharge (ESD). Take extreme care when handling to protect the contacts from static shock. ESD will destroy SDHC and SxS Cards! Do not store outside of camcorder or storage case!



#### **LINE VOLTAGE THRESHOLD**

This camcorder can provide optional 48V Phantom-power for microphones. Do not engage Phantom-power in conjunction with battery-powered microphones! To do so will overload and damage the XLR jack!

### **PACKING AND STORAGE:**

#### **IMPROPERLY OR MESSILY PACKED KITS WILL RESULT IN A FINE!**

**IMPORTANT:** The SDHC Card, MxR/SxS Adaptor, or SxS Cards must be packed in either the camcorder's SxS Card Slots or their storage case. Do not pack loose in the case!

Camcorder is packed right-side up, lens facing to the right. Pack with LCD retracted, screen facing inwards, and lens cap shutter closed to protect lens. Remove Li-Ion Battery for packing.

Wrap the XLR Cable in broad, alternating loops, and bind with velcro-strap, fuzzy-side out.

Pack the included Røde NTG-1 Shotgun Microphone, Pistol Grip, and XLR Cable in their foam slot, in front of the camcorder's lens. Do not remove the microphone from its shockmount!

Wrap all Power Cables in a figure-eight pattern, and bind with their velcro strap, fuzzy-side out. Power cables, Li-Ion battery and AC Adapter should be stored in their clear-vinyl zipper wallet.

#### **PACKING EXAMPLE:**

Spare SxS Cards, or the MxR/SxS Adaptor with SDHC Card, should be packed in the dedicated hard plastic storage case, and packed in the clear-vinyl zipper wallet, along with the Mini USB Cable and SDHC USB Adaptor as well.

Pack the clear-vinyl zipper wallet in the corresponding foam slot next to the camcorder.

Operating Manual and Driver Disk are stored behind the case lid foam.

Do not pinch cables in case lid!



In the event of accident or mishap with this equipment, contact the F&DM Checkout Lab Specialist IMMEDIATELY: Phone (831) 459-4062 – Email [fdmcheckout@ucsc.edu](mailto:fdmcheckout@ucsc.edu)

**IN THE EVENT OF MEDICAL EMERGENCY, DIAL 911.**