

## **EQUIPMENT KIT CHECKLIST PANASONIC AG-HMC150PJ KIT**

### **OPERATION AND SAFETY:**



#### **ELECTROSTATIC SENSITIVE DEVICE**

The SDHC card is sensitive to Electrostatic Discharge (ESD). Take extreme care when handling to protect the gold contacts from static shock. ESD will destroy the SDHC Card!  
Do not store outside of camcorder! DO NOT pack loose inside case or clear-vinyl pouch!



#### **LINE VOLTAGE THRESHOLD**

This camcorder can provide optional 48V Phantom-power for microphones.  
Do not engage Phantom-power in conjunction with battery-powered microphones!  
To do so will overload and damage the XLR jack!

### **PACKING AND STORAGE:**

#### **IMPROPERLY OR MESSILY PACKED KITS WILL RESULT IN A FINE!**

IMPORTANT: The SDHC Card must be packed in the camcorder's SD Card Slot.

Do not pack loose in the case! Make sure the SD Card Slot Lid is closed for packing!

Camcorder is packed on its side, lens facing to the right. Pack with LCD closed, screen facing in, and lens cap on to protect lens. Remove Li-Ion Battery for packing.

Wrap all Power Cables in a figure-eight pattern, and bind with their velcro strap, fuzzy-side out. Power cables, Li-Ion batteries and AC Adapter should be stored in their clear-vinyl zipper wallet.

Pack the USB SD Card Reader in the clear-vinyl zipper wallet with the power components.  
Take care not to crush or bend the USB SD Card Reader!

#### **PACKING EXAMPLE:**

Wrap XLR Cable in broad, alternating loops, and bind with velcro-strap, fuzzy-side out.

Place the clear-vinyl zipper wallet and the wrapped XLR Cable in the foam slot, side-by-side.

Operating Manual is stored behind the case lid foam. Do not pinch cables in case lid!



In the event of accident or mishap with this equipment, contact the F&DM Checkout Lab Specialist IMMEDIATELY: Phone (831) 459-4062 – Email [fdmcheckout@ucsc.edu](mailto:fdmcheckout@ucsc.edu)

**IN THE EVENT OF MEDICAL EMERGENCY, DIAL 911.**